

HP Pavilion home PC

Quick Setup

快速安裝


© 2004 Hewlett-Packard Development Company, L.P.

Printed in

www.hp.com

1 Keyboard and Mouse

鍵盤和滑鼠



OR
或

Wireless option

Refer to the setup instructions located in your mouse/receiver box.

無線選購裝置

請參閱滑鼠/接收器盒內的安裝指示。




2 Monitor

Refer to setup instructions that came with your monitor.

顯示器

請參閱顯示器隨附的安裝指示。




3 Speakers

Refer to setup instructions that came with your speakers.


喇叭

請參閱喇叭隨附的安裝指示。




4 TV In Connect TV signal to computer

TV 輸入 將電視訊號連接到電腦



OR
或




5 TV Out (TV connections are optional)

TV signal from computer to TV

TV 輸出 (電視連接為自行選擇)

從電腦連接到電視的電視訊號




6 FM antenna Select models only

FM signal to computer

FM 天線 僅限於部分型號

將 FM 訊號連接到電腦



7 Power Connection


Computer to electrical outlet

Grounded connection or connection to surge protector is recommended.


電源連接

將電腦連接到電源插座

建議的連接方式為接地連接或連接到突波保護器。



8 Modem 數據機




Connect modem cable to computer.

將數據機連接線插入電腦。

9 Power On

開啓電源



First, turn on monitor then computer.

先開啓顯示器再開啓電腦的電源。

**Your PC may look different from the ones shown here.
Component, connector location, type, and number vary by model.**

您的電腦外觀可能與下圖所示的電腦不同。
各個型號的組件、接頭位置、類型和編號亦不相同。

